ASUS

Padfone™

Quick Start Guide

E7190

First Edition
March 2012

Copyright © 2012 ASUSTek Computers, Inc.

All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUS Telecom (“ASUS”).

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification of alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners’ benefit, without intent to infringe.

Thank you for purchasing another awesome ASUS product!

Before you start, ensure that you have read all the safety information and operating instructions in the **Important Notices** to prevent injury or damage to your device.

NOTE: This bundled Quick Start Guide is for reference only and is subject to change without prior notice. For the latest updates and more detailed information, please visit **www.asus.com**.

Getting to know your PadFone

Front features



Rear features



Installing the SIM card and battery

Before you can start using your PadFone, you need to install a Subscriber Identity Module (SIM) card and the battery.

To install the SIM card and battery:

Remove the PadFone back cover

1

2

3



Install the SIM card

Install a micro SD card



15060-05R00000

Install the battery



Replace the backcover



Charging your PadFone

After installing your SIM card and battery, we strongly recommend that you charge the battery fully before turning your device ON.

To charge your PadFone:

1. Connect the power plug into the USB charger. Ensure that the power plug is attached securely in place.
2. Connect the USB connector into the USB charger's USB port.
3. Connect the micro USB connector into your PadFone.
4. Insert the power plug into a wall socket.



CAUTION! Double-check the connections and ensure that the power plug is securely attached to the AC Adapter to prevent overheating and damage to the cables, adapter, or device.

NOTICE

- Use only the power adapter that comes with your device. Using a different power adapter may damage your device.
- Using the provided USB charger and USB cable to connect your PadFone to a power outlet is the best way to charge your PadFone.
- The input voltage range between the wall outlet and this adapter is AC 100V - 240V; the output voltage through the micro-USB cable is DC 5V, 2A.

Turning your PadFone on or off

Press the power key on top of your PadFone to turn the device on or to turn it off.

IMPORTANT The first time you turn your PadFone on, you will see the Welcome screen. Touch the menu to select your preferred language then touch **Next Step**. Follow the succeeding onscreen instructions to set up your PadFone.

To turn your PadFone off:

1. Press the power key for about five (5) seconds until the power off menu appears.
2. Touch **Power Off** then touch **OK** to confirm.